


# 742 TRAINING WHEEL ASSEMBLY



## ASSEMBLY INSTRUCTIONS :

1. ASSEMBLE WHEEL TO BRACKET WITH NUTS AS ILLUSTRATED. TIGHTEN NUTS SECURELY TO BRACKET.
2. REMOVE REAR AXLE NUT FROM BIKE, ONE SIDE ONLY. (LEAVE LOCKING WASHER, IF SO EQUIPPED, NEXT TO BIKE FRAME).
3. PLACE BRACE ARM ON AXLE WITH OPEN SLOT AROUND BIKE FRAME AND MOUNT WHEEL-BRACKET ASSEMBLY TO REAR AXLE.

NOTE : IF NEEDED, PLACE HEAVY SPACER WASHERS ON REAR AXLE SO THAT BRACE ARM AND/OR BRACKET WILL CLEAR ANY OBSTRUCTIONS ON THE BIKE FRAME.

4. REPLACE AXLE NUT. ADJUST WHEEL TO 1/2" FROM GROUND AND TIGHTEN NUT SECURELY.
5. REPEAT FOR OTHER SIDE.